

Approved Healthcare Disinfectants List:

Clorox Bleach w/Water (1:4)
70% Isopropyl Alcohol
91% Isopropyl Alcohol
Ecolab Oasis 146 Multi-Quat Sanitizer
3M HB Quat Disinfectant 25L
3M HB Quat Disinfectant 23H
Cavi Wipes XL
Diversey Virex II 256 Broad Spectrum Disinfectant
Oxivir Five 16 Concentrate
Oxivir TB Spray
Clorox Disinfectant wipes
Sani-Cloth AF3
Super Sani-Cloth
Clorox Germicidal Spray
Clorox Healthcare Bleach Germicidal Wipes
Citrace
Steris Coverage Spray HB
Ecolab 456
Ecolab Oxycide
Virox 5 Concentrate
Virox 5 RTU (16:1)
Wex-Cide 128
ProSpray Wipes cleaner
Clorox Healthcare Hydrogen Peroxide Cleaner Disinfectant Wipes
Virex II 256 1:256 Diluted
Clinell Disinfectant Wipes

Stain Resistance -CFFA Standard

Ink/Permanent Marker/Crayon/Ballpoint Pen

Indigo Denim Transfer

Coffee/Chocolate

Mustard/Wine/Orange Juice

Vegetable Oil

Lipstick/Mascara

Blood/Urine/Sweat/Stomach Acid

Betadine

Nail Polish Remover/ Moisturizer

Suntan Lotion

Coppertone Ultraguard Broad-Spectrum Sunscreen Continuous Spray SPF 50

John's Baby Oil

Shea Moisture Jamaican Black Castor oil

Note: The cleansers above have been tested internally by Sileather. Many cleansers are designed for PVC coated fabrics (vinyl), while Sileather is a 100% silicone coated fabric. The main purpose is to test the chemical reaction between these cleansers and Sileather. It is not recommended for general cleaning purposes.

- Common stains can be removed with clean water. For lipstick, markers and other stubborn stains, it is recommended to use isopropyl alcohol and clean within 24 hours. It is recommended that you clean and maintain your Sileather products on a monthly basis.
- Please always spot clean before applying any cleanser to Sileather materials. Avoid the use of rough and scratchy cleaning tools.
- Avoid leaving cleanser residue on the surface.
- Please do not use any polish or post treatment on Sileather.
- Please use a clean, soft cloth (or sponge) that does not fade.
- Alcohol and alcohol-based cleaners are combustible. Please handle with care. Use only a small amount of detergent to avoid any source of ignition. Wear protective gloves and be sure to clean in a well-ventilated area.
- Please keep hydrocarbons, benzene solvents, and cyclosiloxane oligomers away from Sileather fabrics.